


## ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

204184 *Mirror* 

REVISION 0 : 06/17/2015 REVISION 1 : 07/04/2017 REVISION 2 : 03/23/2018 REVISION 3 : 11/05/2019

PAGE 1 OF 3

COASTERFURNITURE.COM

### ITEM: 204184

#### **ASSEMBLY INSTRUCTIONS**

# COASTER<sup>®</sup>


#### **ASSEMBLY TIPS:**

- 1.Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



#### **WARNING!**

- 1.Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

15 MINUTES

### **PARTS IDENTIFICATION**

DRESSER A FROM BOX ITEM 204183



1PC

MIRROR SUPPORT
C (PACKED WITH
DRESSER)



2PCS

B MIRROR



1PC

#### HARDWARE IDENTIFICATION

BOLT (1/4" x 32mm - RBW)



6PCS

3 FLAT WASHER (1/4" x 19 x 1.5mm - RBW)



6PCS

2 LOCK WASHER (1/4" - RBW)



6PCS

4 ALLEN WRENCH (4MM - RBW)




1PC

## ITEM:**204184**


#### **ASSEMBLY INSTRUCTIONS**

# COASTER\*

### STEP 1




# STEP 2 COMPLETE





## ITEM:**204184**





**Note**: Dimension tolerance  $\pm 5\%$