

ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

205295 *Chest*

REVISION 0 : 05/10/2017 REVISION 1 : 08/30/2017 REVISION 2 : 02/05/2020

ITEM: 205295

ASSEMBLY INSTRUCTIONS

COASTER

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

5 MINUTES

PARTS IDENTIFICATION

A CHEST




1PC

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

STEP 1



STEP 2 COMPLETE






COASTERFURNITURE.COM

PAGE 2 OF 2



Inner Size of Drawer: 26.75"W X 12.50"D X 4.00"H X 0.25"T



Note: Dimension tolerance ±5%