

E-Commerce by Enitial Lab

ASSEMBLY INSTRUCTIONS

MODEL#

CM3212SC-2PK

Questions?

GIVE US CALL: 1-888-980-5122 MON-FRI 8:30AM - 5:30PM (PST)

TOOLS REQUIRED



Allen Wrench

(Included)




2 - People Recommended

ASSEMBLY RATING



EASY ── DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



VERSION # 20-09-07





Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. Our customer service department is available Monday – Friday 8:30 AM – 5:30 PM Pacific and can help with assembly questions as well as, if necessary, replacing damaged or missing parts. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Consumer Hotline Toll-Free 1-888-980-5122



WEBSITE www.foagroup.com









foagroup



Monday to Friday 8:30AM- 5:30PM (PST)



E-MAIL cs.ec@foagroup.com



FurnitureOfAmerica



	Are you missing anything?	Check out our Quick Tips!
	Double-check all parts, hardware and accessories listed on Page 6 are accounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
	Should we send any replacements?	Prep Time!
	Are there any irregularities or flaws in the parts? We can send replacements!	Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.




Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CHAIR CM3212SC-2PK



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



PARTS













Chair Back

Cushion Seat


Front Leg

HARDWARE

(#A) 1pc x2
















Bolt Ø5/16" x 1-1/2"

Bolt Ø5/16" x 2-3/8"

Bolt Ø5/16" x 2-3/4"

Lock Washer Ø5/16"

#E) 9pcs x2




Flat Washer Ø5/16"

#F) 1pc x2



Allen Wrench M4




ASSEMBLY INSTRUCTIONS

1. Place the backrest w/legs (#1) Part #1x1pc onto a protected surface. Part (#2) x1pc Hardware (#A) x1pc #D #2 Hardware #D x1pc #E Hardware (#E) x1pc #1 2. Prepare a bolt assembly by inserting a lock washer 3. Align the seat cushion (#2) to the hole (#D) onto the bolt (#A) along the backrest w/legs (#1), then then a flat washer (#E) insert the bolt assembly into the center onto that same bolt (#A). hole and secure using the Allen wrench.


2

Hardware #C x4pcs
Hardware #D x4pcs
Hardware #E x4pcs



ASSEMBLY INSTRUCTIONS

Part #3x2pcs Hardware (#B) x4pcs Hardware(#E) x4pcs Hardware(#D) x4pcs #3 #E #D #B 2. Align the front legs (#3) to the holes 1. Prepare 4 bolt assemblies by inserting a along the front corners of the seat (#2), lock washer (#D) onto the bolt (#B) then then insert 2 bolt assemblies into each a flat washer (#E) onto that same bolt (#B).



corner and secure using the Allen wrench.

ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.