



ASSEMBLY INSTRUCTIONS

**MODEL : 0361A/B & 0362A
YLIME
DRESSER**


**(BOX 1)
BOX OF DRESSER**

NO	ITEM	QTY
	DRESSER	
A		1 PC



HARDWARE LIST

NO	ITEM	QTY
	12V+12W+1A Adaptor With ETL Certificate	
1		1 PC

STEP 1 : Remove The Adaptor (1) from the Top Drawer then Connect the LED terminal socket which is place at back of Dresser (A) as shown.



STEP 2 : Pull out the drawer to find the switch button as shown.



COMPLETED ASSEMBLY

NOTE : MUST TIGHTEN SCREWS PERIODCALLY OR SCREWS WILL BECOME LOOSE.CHECK TIGHTNESS OF ALL SCREWS EVERY 6-8 WEEKS.